



## Water Cooler Accessories

### Drip Tray Drain Options



PUMP2L

A Waste System - WASTEKIT114 - connecting the Drip Tray to the waste - Factory Installed



WASTEKIT114

A Pumped Waste System - PUMP2L - pumps the waste water from the Drip Tray over a distance of 100m and a rise of 5m - Factory Installed

3 litre Overflow Kit - WB4465 - connects the Drip Tray to a 3 litre alarmed Overflow Container (for Alpha1/Delta4 EV3565.) The Container has a tap to empty without removing it - Factory Fitted or Self Installed



WB4465



OVERFLOW10

10 litre Overflow System - OVERFLOW10 - with alarm to signal when full - Factory Fitted

Drip Tray Modification - DRIP TRAY MOD516 - connects a 5/16" John Guest pipe to the Drip Tray and instead of guiding it into an Overflow Tank, connecting it to a Bulkhead connector at the back of the Cooler and from there straight into the mains drain - Factory Fitted or Self Installed



DRIP TRAY MOD516

### Fixing the Cooler to the Wall & Floor



BRACKET

A strong metal Cowling to fix the Water Cooler to the wall and floor - COWLING334488 - Self Installed (also available for Fountains - CA61)

Wall Bracket - BRACKET - to fit all Coolers and Fountains. Self Installed



COWLING

### Flood Prevention



FPVRAIL

Flood Prevention that works! A Flood Prevention Valve linked to a timer turns the mains water off overnight and at weekends. Comes as part of the Installation Rail - FPVRAIL - or can be purchased separately as FPVKIT

