## GLASSFILLER CL Stand Alone Contactless Swan Neck Tap

## The GLASSFILLER CL is a Stand Alone Contactless Swan Neck Tap

To avoid hand to tap bacterial contamination



## Description

- The Contactless GLASSFILLER CL can replace manual Swan Neck Taps on a variety of Undersink Chillers, including our UC800 which converts to a UC800CL
- The GLASSFILLER CL Infra Red Sensor is activated by a hand hovering over it at a distance of 2cm – 5cm
- It is connected to an inlet solenoid which opens the water supply to the tap as the hand hovers over the sensor. If you remove the hand, the dispensing will stop
- The Solenoid Valve is powered by two 3V batteries with a tested life span of 86.000 Solenoid activations
- The GLASSFILLER CL is programmed to stop dispensing after 6 seconds. If that is insufficient to fill your glass or bottle, place your hand again over the sensor to continue dispensing

Description	Dimensions (mm) ( H x W x D )	Weight (KG)
UC800CL	290 X 410 X 210	12.5
FONT10CL	220 X 310 X 345	2.7
GLASSFILLER CL	300Н	-

