








AA EZYTAP75
PARTS LIST

No	Description	Code	Remarks
101,102,103,104,110	CASING COMPLETE	EZ101	
111	CABLE GLAND	EZ111	
112	INTERNAL EARTH WIRE	EZ112	
113	WIRING TO THERMOSTAT CONTROL	EZ113	
114	WIRING TO THERMOSTAT	EZ114	
115	W301 WIRING	EZ115	
131,132,133	¼" S/S TUBE FITTING	EZ131	SECURE FITTING
141	GROMMET	EZ141	HOT OUTLET
142	SCREW	EZ142	COMMS CONNECTOR
143	SCREW NUT	EZ143	COMMS CONNECTOR
150	POWER CABLE	EZ150	HARD WIRED
151	COMMS WIRING	EZ151	
152	CIRCUIT BREAKER	EZ152	
152A	CIRCUIT BREAKER WIRES	EZ152A	
155	MAIN PCB	EZ155	
156	SOLENOID	EZ156	3 SOLENOIDS
156A	COLD SOLENOID WIRE	EZ156A	
156B	HOT SOLENOID WIRE	EZ156B	
156C	AMBIENT SOLENOID WIRE	EZ156C	
157	PCB PLATE	EZ157	
160	PHILIPS SCREW	EZ160	X2 4*50
161	PHILIPS SCREW	EZ161	X2 3/16*10
163	INTERNAL WASHER	EZ163	X8
164	HEX NUT	EZ164	X2
176	1/4" ELBOW STEM	EZ176	JG FITTING
177A	ROUND HEAD SCREW	EZ177A	X2 4*25
178	SELF TAPPING SCREW	EZ178	X2 1/4* 3/8
179	FLAT HEAD SCREW	EZ179	X20 4*8
201,231,233,255,256	4 LITRE HOT TANK COMPLETE	EZ201	WITH INSULATION
241	HEATER ELEMENT	EZ241	2KW
242	ELEMENT GASKET	EZ242	
243	THERMOSTAT CONTROL	EZ243	RT3463
244	THERMOSTAT CONTROL SCREWS	EZ244	X3 3*8 + WASHERS
245	THERMOSTAT	EZ245	
246	THERMOSTAT SCREWS	EZ246	X2
247	EARTH WIRE HOT TANK	EZ247	

248	TEMPERATURE SENSOR	EZ248	
260,259,261,262,264,265,266	DRAIN HEAD COMPLETE	EZ260	TANK DRAIN
270,272,274,276,278	TANK CLAMP COMPLETE	EZ270	
280	SILICONE PIPE	EZ280	40MM
281	FEP TUBE	EZ281	265MM
450,403,411,412,415,417,420,451,456,458	EXPANSION CHAMBER COMPLETE	EZ450	
001	TAP COMPLETE	EZ001	
001D	TAP DUMMY	EZ001D	For demo only





EZ001 and EZ001D